

ELECTRIC AERIAL ORDER PICKER

TT045-IPE

Series 2

OPERATION INSTRUCTION



CONTENTS

PREFACE 2

I APPLICATION 2

II SAFETY PRECAUTIONS 2

III TECHNICAL SPECIFICATIONS 7

IV OPERATING GUIDE 8

V LABELS 9

VI MAINTENANCE GUIDE 12

VII STORAGE AND TRANSPORTING 15

VIII ELECTRICAL DIAGRAM 16

IX HYDRAULIC DIAGRAM 16

X TROUBLE SHOOTING 17

XI EXPLODED VIEW AND PARTS LIST 18

PREFACE

Read this instruction carefully before the machine is taken into use to avoid errors. Correct operations and regular inspections are factors of vital importance for the operating economy and lifetime of the machine.

These important parts are described in the following related sections.

All the information contained in this booklet is based on the data available at the time of printing, the manufacturer reserves the right to modify its products at any time, without notice and without liability. It is therefore advisable to regularly check for any changes.

This manual is a very important tool. Keep it with the machine at all times.

I APPLICATION

Electric Aerial Order Picker is the best equipment for goods picking and handling. It's intended for use on plane and level floors. Easy driving and operating. Lift or fall steadily. Safe and reliable. Suitable for order picking in the goods distribution warehouses.

This manual is a very important tool. Keep it with the machine at all times.

II SAFETY PRECAUTIONS

GENERAL


This section outlines the necessary precautions for use the machine properly, it is mandatory that a daily routine be established based on the content of this manual. A maintenance program, using the information provided in this manual, must also be established by a qualified person and must be followed to ensure that the machine is safe to operate.

The owner/user/operator/lessor/lessee of the machine should not accept operating task until this manual has been read, training is accomplished, and operation of the machine has been completed under the supervision of an experienced and qualified operator.

If there are any questions with regard to safety, training, inspection, maintenance, application, and operation, please contact the manufacturer.

Trip and Fall Hazard

- Before operating the machine, make sure all railings and gates are fastened in their proper position.



- Keep both feet firmly positioned on the platform floor at all times. Never use ladders, boxes, steps, planks, or similar items on platform to provide additional reach.

- Never use the mast assembly to enter or leave the platform.
- Use extreme caution when entering or leaving platform. Ensure that the platform is fully retracted. Face the machine when entering or leaving the platform. Always maintain “three point contact” with the machine, using two hands and one foot or two feet and one hand at all times during entry and exit.
- Platform-to-structure transfers at elevated positions are discouraged. Where transfer is necessary, enter/exit through the gate only with the platform within 1 foot (0.3m) of a safe and secure structure. 100% tie-off is also required in this situation utilizing two lanyards. One lanyard must be attached to the platform with the second lanyard attached to the structure. The lanyard connected to the platform must not be disconnected until such time the transfer to the structure is safe and complete.

Electrocution Hazard




TABLE 1 MINIMUM SAFE APPROACH DISTANCE (M.S.A.D.)


VOLTAGE RANGE (PHASE TO PHASE)	MINIMUM SAFE APPROACH DISTANCE-Feet (m)
0-50KV	10(3)
Over 50KV to 200KV	15(5)
Over 200KV to 350KV	20(6)
Over 350KV to 350KV	25(8)
Over 500KV to 750KV	35(11)
Over 750KV to 1000KV	45(14)
NOTE: This Minimum Safe Approach Distance shall apply except where employer, local, or governmental regulations are more stringent.	

Maintain a clearance of at least 10 ft (3m) between any part of the machine and its occupants, their tools, and their equipment from any electrical line or apparatus carrying up to 50,000 volts. One foot (0.3m) additional clearance is required for every additional 30,000 volts or less.

The minimum safe approach distance may be reduced if insulating barriers are installed to prevent contact, and if the barriers are rated for the voltage of the line being guarded. These barriers shall not be part of (or attached to) the machine. The minimum safe approach distance shall be reduced to a distance within the designed working dimensions of the insulating barrier. This determination shall be made by a qualified person in accordance with employer, local, or governmental requirements for work practices near energized equipment.

Tipping Hazard


- The user should be familiar with the surface before driving. Do not exceed the allowable side slope and grade while driving.
- Do not elevate platform or drive with platform elevated while on a slope, or on an uneven or soft surface.



- Before driving on floors, bridges, trucks, and other surfaces, check allowable capacity of the surfaces.
- Never exceed the maximum platform capacity. Distribute loads evenly on platform floor.
- Keep the chassis of the machine a minimum of 2 ft. (0.6m) from holes, bumps, drop-offs, obstructions, debris, concealed holes, and other potential hazards at the ground level.
- Never attempt to use the machine as a crane. Do not tie-off machine to any adjacent structure.
- Do not increase the platform size with unauthorized deck extensions or attachments, increasing the area exposed to wind will decrease stability.
- If mast assembly or platform is caught so that one or more wheels are off the ground, the operator must be removed before attempting to free the machine. Use cranes, forklift trucks, or other appropriate equipment to stabilize machine and remove personnel.

Crushing and Collision Hazard

- Personal protection equipment must be worn by all operating and ground personnel.
- Check work area clearances above, on sides, and bottom of platform while driving and lifting or lowering platform.



- During operation, keep all body parts inside platform railing.
- Always post a lookout when driving in area where vision is obstructed.
- Keep non-operating personnel at least 6 ft. (1.8m) away from machine during all driving operations.
- Limit travel speed according to conditions of ground surface, congestion, visibility, slope, location of personnel, and other factors causing hazards of collision or injury to personnel.
- Be aware of stopping distances in restricted or close quarters or when driving in reverse.
- Do not drive at high speeds in restricted or close quarters or when driving in reverse.
- Exercise extreme caution at all times to prevent obstacles from striking or interfering with operating controls and persons in the platform.
- Ensure that operators of other overhead and floor level machines are aware of the aerial order picker's presence. Disconnect power to overhead cranes.
- Warn personnel not to work, stand, or walk under a raised platform. Position barricades on floor if necessary.

WARNING

FAILURE TO COMPLY WITH THE SAFETY PRECAUTIONS LISTED IN THIS MANUAL COULD RESULT IN MACHINE DAMAGE, PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.

PRE-OPERATION**Pre-Service Check**

1. If the machine has been damaged during transport, it must not be put into service, and you should immediately contact your dealer.
2. The machine has been lubricated before delivery, and the hydraulic unit has been filled with hydraulic oil. Check the oil level, fill up if necessary
3. If a battery has been supplied with the machine, the battery is charged. Check and recharge if necessary.
4. Check the connector, tighten up if necessary.

Personnel Training

The aerial order picker is a personnel-handling device; so it is necessary that it be operated and maintained only by trained personnel.

Persons under the influence of drugs or alcohol or who are subject to seizures, dizziness or loss of physical control must not operate this machine.

Operator Training

Operator training must cover:

1. Use and limitations of the controller and emergency switch in the platform and at the ground, the key switch and the method of manual lower platform.
2. Control labels, instructions, and warnings on the machine.
3. Rules of the employer and government regulations.
4. Use of approved fall protection device.
5. Enough knowledge of the mechanical operation of the machine to recognize a malfunction.
6. The safest means to operate the machine where overhead obstructions, other moving

- equipment, and obstacles, depressions, holes, drop-offs are present.
7. Means to avoid the hazards of unprotected electrical conductors.
 8. Specific job requirements or machine application.

Training Supervision

Training must be done under the supervision of a qualified person in an open area free of obstructions until the trainee has developed the ability to safely control and operate the machine.

Operator Responsibility

The operator must be instructed that he/she has the responsibility and authority to shut down the machine in case of a malfunction or other unsafe condition of either the machine or the job site.

NOTE: The Manufacturer or Distributor will provide qualified people for training assistance with the first unit(s) delivered and from that time forward as requested by the user or his/her personnel.

Workplace Inspection

- The operator is to take safety measures to avoid all hazards in the work area prior to machine operation.
- Do not operate or raise the platform while on trucks, trailers, railway cars, floating vessels, scaffolds or other equipment unless approved in writing by the manufacturer.
- Elevate the platform only on the firm and level surface.
- Don't use the machine outdoor when it's lightning or storm.
- Don't use the machine when wind speed $\geq 12.5\text{m/s}$.
- This machine can be operated in temperatures of -20°C to 40°C . Consult the manufacturer for operation outside this range.

Machine Inspection

- Check performance and function of the machine before operating it.
- Do not operate this machine until it has been serviced and maintained according to requirements specified in this manual.
- Ensure all safety devices are operating properly. Modification of these devices is a safety violation.

WARNING

MODIFICATION OR ALTERATION OF AN AERIAL ORDER PICKER SHALL BE MADE ONLY WITH PRIOR WRITTEN PERMISSION FROM THE MANUFACTURER

- Do not operate any machine on which the safety or instruction placards or decals are missing or illegible.
- Avoid any build up of debris on platform floor. Keep mud, oil, grease, and other slippery substances from footwear and platform floor.
-

III TECHNICAL SPECIFICATIONS

Technical specifications and major dimensions are shown in FIGURE 1 and TABLE 2, respectively.





FIGURE 1 PICKER SCHEMATIC DRAWING

TABLE 2 TECHNICAL SPECIFICATIONS

MODEL		TT045-IPE
Maximum Platform Height(h2)	mm	4500
Maximum Machine Height(h3)		5940
Rated Capacity	kg	300
Platform Size	mm	700×600
Dock Size	mm	660×320
Maximum Drive Speed (Stowed)	km/h	4
Maximum Drive Speed (Raised)		1.1
Minimum Turning Radius	mm	0
Gradeability	%	25
Driving Motor	v/kw	2×24/0.4~0.5
Lifting Motor	v/kw	24/2
Battery	v/Ah	2×12/120
Charger	v/A	24/12
Overall Length(L)	mm	1565
Overall Width(W)		794
Overall Height(h1)		1990
Net Weight	kg	662

IV OPERATING GUIDE



Platform Control Panel

- | | |
|--------------------------------|---------------------------------------------------------------------------------------|
| 1 Drive function select button | 5 Horn button |
| 2 Drive speed button | 6 Lift function select button |
| 3 Red Emergency Stop button | 7 Proportional control handle and function enable switch for lift and drive functions |
| 4 LED | |

PLATFORM CONTROL PANEL


- 1 Drive function select button
Press this button to activate the drive function.
- 2 Drive speed button
Press this button to activate the slow or fast drive function.
- 3 Red Emergency Stop button
Push in the red Emergency Stop button to the off position to stop all functions. Pull out the red Emergency Stop button to the on position to operate the machine.
- 4 LED
Diagnostic read out and battery charge indicator.

5 Horn Button

Push the horn button and the horn will sound. Release the horn button and the horn will stop.

6 Lift function select button

Press this button to activate the lift function.



7 Proportional control handle and function enable switch for lift and drive functions

Lift function: Press and hold the function enable switch to enable the lift function on the platform control handle. Move the control handle in the direction indicated by the blue arrow and the platform will raise. Move the control handle in the direction indicated by the yellow arrow and the platform will lower. The descent alarm should sound while the platform is lowering.

Drive function: Press and hold the function enable switch to enable the drive function on the platform control handle. Move the control handle in the direction indicated by the blue arrow on the control panel and the machine will move in the direction that the blue arrow points. Move the control handle in the direction indicated by the yellow arrow on the control panel and the machine will move in the direction that the yellow arrow points.

MATTERS NEEDING ATTENTION

The goods should be put on the platform evenly. And forbid to overload.

Forbid to stand under the platform when it is working or driving.

It must be operated on the smooth and solidity road.

Please use Protector during overhaul or check batteries and cables connector.

Please cut off the power and the emergency switch if it is not work for a long time.

After the platform elevated, if the machine has malfunction, you could use the emergency descent valve let it down by pull the manual descent lever out.

For saving the electricity, please cut off the power after operating.

V LABELS

The following labels are visible on the machine:




FIGURE 4 LABEL POSITION

TABLE 3 ZDYT3-3.5T/4.0T/4.5T LABELS LISTW

Item	Code No.	Description	Qty
1	9443025	Notice—Capacity 300 kg	1
2	9423011	Notice—Allowed Number of persons	1
3	9443015	Warning—Read the instructions	1
4	9443013	Label indicating forbid put the goods out of platform or anybody below the platform while operating, and the protector must be use when inspecting	1
5	9441021	Danger—Please don't stand around the machine	2
6	9441027	Warning—Here without fork	3
7	9441023	Notice—Tyre Max. capacity 350 kg	4
8	9443021	Notice—Please cut off the power after operating.	1
9	9443019	Notice—Recharging lasts at least 12 hours.	1
10	9441019	Warning—Timely charging	1
11	9441017	Notice—Charging usage	1
12	9441025	Warning—Here for fork	2
13	9341013	Notice—Draw out to manual lower platform	1
14	9441011	CE label	1
15	9241013	Plate that identifies the kind of picker	1
<p>Labels Inspection: Use the following labels to verify that all decals are legible and in correct place.</p>			

CAPACITY:300kg
9443025

ALLOWED NUMBER OF PERSONS
ONE
9423011

WARNING
THE MANUFACTURER SHALL NOT BE HELD LIABLE IN CASE OF FAULTS OR ACCIDENTS DUE TO NEGLIGENCE, INCAPACITY, INSTALLATION BY UNQUALIFIED TECHNICIANS AND IMPROPER USE OF THE MACHINE.
DO NOT OPERATE THIS MACHINE UNTIL YOU READ AND UNDERSTAND ALL THE DANGERS, WARNINGS AND CAUTIONS IN THE MANUAL.
MAGYE



DANGER

Please don't stand
9441021


9441027

MAX. 350Kg

9441025


NOTICE:
FOR SAVING THE ELECTRICITY, PLEASE CUT OFF THE POWER AFTER OPERATING.
9443021

NOTICE:
For the initial use or use after long periods of storage. Please charge the battery before use. Recharging lasts at least 12 hours.
9443019




WARNING

TIMELY CHARGING
When operating the machine , if you find it can not be travelling, lifting or steering etc.,please charge in time.




9441019




NOTICE


CHARGING USAGE
This is only one position to charge. If you charge at any other error situation, this will be result in dangerous and hazardous aftermath.



9441017



9441011



AERIAL ORDER PICKER

No.

ITEM SPECS

VOLTAGE V

CAPACITY kg

POWER kw

PLATFORM HEIGHT m

OLEO Mpa

DELIVERY DATE

DIMENSION x x m

9241013

VI MAINTENANCE GUIDE

DAILY CHECK

1. Check that the battery is fully charged (see also the section of the battery).
2. Lift the platform to its top position to check that there is enough hydraulic oil in the system. Refill it if necessary with YA-N32 or similar oil.

WEEKLY CHECK

The user of the picker should spend a few minutes every week on cleaning. Special attention should be paid to the wheels and axles, see if there is thread, rags and the like blocked on.

HALF-YEAR CHECK

1. Lubricate the lifting chain. Check the chain for wear.
2. Check and tighten possible loose screws and nuts and the cable joints of the battery.
3. Check brush wear in the pump motor, and take away possible irregular so that a good contact is maintained.

OIL CHANGE IN THE HYDRAULIC SYSTEM

We recommend to change the hydraulic oil after one month's operation (or 200 hours), and even if the operation time has not reached, change the oil once a year. Use hydraulic oil YA-N32 or the like. Oil should be filtered clean and maintained adequate.

When you have lifted and lowered the platform 2 or 3 times, there is no more air in the system, and the machine will again work normally. If the lift height has not been obtained it is necessary to refill.

Forbid to dump the dirty hydraulic oil anywhere at random after the hydraulic oil is changed. The dirty hydraulic oil must be subject to special prescription and comply with the current legal provisions in the area and country where the machine is used.

BATTERY CHARGER

Electric aerial order picker provide maintenance free battery. Keep dry clean and charge it as required can extend the service life of battery.




FIGURE 5 CHARGER PANEL

When AC input, the fan will running, charging indicator will flash showing yellow. When charging is over, the charging indicator becomes green. Please cut off the power first and then pull the AC input plug out.

NOTICE

When battery indicator display 30%, please charge in time, and choose the fit voltage. Recharging lasts at least 12 hours. The machine's platform drive and elevate functions are disabled when the battery charge. If the machine will stop using for a long time, please charge in the fixed time.

WARNING

For saving the battery, when operate is finished, please turn off the Key switch, pull out the key.

VII STORAGE AND TRANSPORTING

STORAGE

Electric Aerial Order Picker must be stowed in an upstanding position, in order to prevent the oil and the electrolyte overflow, during transporting and storing. When stores it, it must be kept clean and keep far away from the damp and bad condition. The temperature of environment should not be more than 40°C. If the battery isn't worked for a long time, it should be recharged timely.

TRANSPORTING, LIFTING AND TIE DOWN PROCEDURES

All TT Series Model Pickers may be transported to a work site using the following methods:

- Driving the machine there by itself if travel surface area permits.
- Loaded, in an upstanding position only onto a heavy-duty vehicle with the payload capacity capable of supporting the full weight of the machine (Check the gross weigh of machine in TABLE 2).
- Moved with a forklift truck by insert its forks into sockets of the chassis.
- Truck transport

CAUTION

DO NOT TRANSPORT THE MACHINE SIDE DOWN DUE TO LEAKAGE OF ACID LIQUID FROM THE BATTERIES OR HYDRAULIC OIL FROM THE HYDRAULIC RESERVOIR.

IMPORTANT

DO NOT ATTEMPT TO DRIVE OR PUSH THE MACHINE ONTO OR OFF A TILTER.

THE ZDYT MACHINES POWER MODULE COULD SUSTAIN SERIOUS DAMAGE WHEN THE UNIT IS TOWING AT SPEEDS GREATER THAN 2 MPH.

IMPORTANT

APPLY EXCESSIVE FORCE ON THE MACHINE (EXCEED WHEEL LOAD), CAN LEAD TO COMPONENTS DAMAGE OF THE WHEELS.

The chain should be securely tightened with a force of approximately 100 lb. applied two feet from the pivot handle.

Fork-Lift Truck Transport

All TT Model Pickers are equipped with wide fork pockets. This allows the machine to be either transported around a work area or lifted onto a higher level using a standard fork-lift truck.

NOTE: Fork-lift trucks must be capable of handling the gross weight of the machine.




FIGURE 6 FORK LIFT POCKETS

VIII ELECTRICAL DIAGRAM




FIGURE 7 ELECTRICAL DIAGRAM
TABLE 4 ELECTRIC APPLIANCES

sign	descreption	model	sign	descreption	model
FU2	start technology	100A	FU2	start technology	10A
E	battery	MF120/20H 12V-120AH	SB2	key switch	ZB2BG2C/ZB2BZ101C-6A
M1	pump motor	W8010-24V-2.0KW	SB1	emergency switch	ZB2BS54C/ZB2BZ102C-6A
FU1	start technology	100A	IN/OUT	up/down controller	IN4004-4-I/O (6A/600V)
KM1	main contactor	MZJ-200S/1201B DC12V/100A	M1	drive motor	113MP 0.4KW 24V /20A 1.4NM
KM2	pump contactor	W800801-1 DC12V 80%	M2	drive motor	113MP 0.4KW 24V /20A 1.4NM
VD	diode	1N4004 6A/600V	KA	charger relay	SD1224L battery charger(inner)
Rnee	controller	D51109.01 24/100A	up-controller		
SQ1	limit switch	AZ8 104 5A250VAC	JSM	joystick(up)	D51122.01 24V LED
YV	solenoid	DC24V			

IX HYDRAULIC DIAGRAM














FIGURE 8 HYDRAULIC DIAGRAM

X TROUBLE SHOOTING

Battery indicator lights (6) on the control panel are a battery gauge. It is used to display electric quantity or malfunction. The battery Gauge has ten bars. They are not flash when the machine is good. If the picker has malfunction, they will flash. The detailed trouble is as follows:

1 Bar 	The battery needs charging or there is a bad connection to the battery. Check the connections to the battery. If the connections are good, try charging the battery.
2 Bar 	The left hand motor* has a bad connection. Check the connections to the left hand motor.
3 Bar 	The left hand motor* has a short circuit to a battery connection. Contact your service agent.
4 Bar 	The right hand motor* has a bad connection. Check the connections to the right hand module.
5 Bar 	The right hand motor* has a short circuit to a battery connection. Contact your service agent.
6 Bar 	The machine is being prevented from driving by an external signal. The exact cause will depend on the type of picker you have, one possibility is the battery charger is connected.
7 Bar 	A joystick fault is indicated. Make sure that the joystick is in the center position before switching on the control system.
8 Bar 	A control system fault is indicated. Make sure that all connections are secure.
9 Bar 	The parking brakes have a bad connection. Check the parking brake and motor connections. Make sure the control system connections are secure.
10 Bar 	An excessive voltage has been applied to the control system. This is usually caused by a poor battery connection. Check the battery connections.

WARNING

Do not wear metal frame glasses, metallic necklaces or chains while working on any electrical equipment. Also do not wear any ring, watch or bracelet while operating electrical equipment.

XI EXPLODED VIEW AND PARTS LIST

FIGURE 9 EXPLODED VIEW




TABLE 5 PARTS LIST

ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION	QTY
1	Cover	1	39	Crew M8x16	8
2	Screw M6x16	2	40	Plat washer 8	30
3	Wheel guard	1	41	Spring washer 8	12
4	Power Switch	1	42	Side adjustor	4
5	Power Switch Seat	1	43	Block	4
6	Battery Charger	1	44	Shim	8
7	Screw M5x10	4	45	Screw M4x8	4
8	Rear wheel	2	46	Main contactor holder	1
9	Plat washer 10	8	47	Screw M4x12	2
10	Spring washer 10	8	48	Main contactor	1
11	Bolt M10x35	8	49	Board	1
12	Chassis	1	50	Control circuit module	1
13	Flat washer 12	15	51	Nut M10	1
14	Spring washer 12	10	52	Reverse buzzer	1
15	Nut M12	12	53	Washer 6	10
16	Caster	2	54	Screw M8x12	8
17	Bolt	1	55	Wheel motor module	1
18	Bearing 6200	1	56	Screw M5x30	2
19	Pulley	1	57	20 Rubber ring	1
20	Screw M6x30	3	58	Control circuit fuse	1
21	Movable pulley carriage	1	60	Main fuse	1
22	Slipper	1	61	Washer 8	4
23	Screw M5x16	6	62	Nut M8	2
24	Guide rail	1	63	Microswitch	1
25	Circlip 16	1	64	Screw M4x30	2
26	Protector	1	65	Screw M6x12	6
27	Semi-odd cable clip	4	66	Tilt alarm	1
28	Screw M4x20	6	67	Hydraulic power unit	1
29	Screw M6x25	4	68	Screw M8x25	4
30	Fixed pulley	2	69	Pump mounting bar	1
31	Fixed pulley seat	1	70	Screw M10x25	2
32	Bolt M10x35	2	71	Screw M4x10	3
33	Nut M10	12	72	Relay holder	1
34	Split pin 3.2X20	4	73	Relay	2
35	Chain tightener	4	74	Solenoid valve	1
36	Split pin 2X16	16	75	lever	1
37	Chain pin	8	76	Breather cap	1
38	Chain between chassis and third stage	2	77	T joint	1

OPERATION INSTRUCTION

ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION	QTY
78	Ground Control	1	117	Bearing 6206	12
80	On/Off panel	1	118	Circlip 62	12
81	Battery	2	119	Circlip 30	12
82	Strip 2	1	120	Button	12
83	Nut M12	1	121	Side piece	12
84	Battery shielding	1	122	Platform	1
85	Washer 6	8	123	Guard bar	2
86	Chain between second stage	2	124	Pin locker	2
87	Bolt M12x25	1	125	Plat washer 5	12
88	Semi-dual cable clip	2	126	Spring washer 5	12
89	Second stage	1	127	Screw M5x12	12
90	1/4 Special bolt	1	128	Pipe clip (Φ25)	2
91	Gasket	4	129	Screw M4x10	4
92	Adaptor	1	130	Dog	2
93	Rubber pad	1	131	Screw M5x25	4
94	Staple bolt	1	132	Turning door	2
95	Seat pad	1	133	Washer 6	32
96	Nut M12	2	134	Screw M6x45	16
97	Cylinder	1	135	Hinge	4
98	Special bolt	1	136	Nut M6	16
99	Gasket	2	137	Controller	1
100	Oil hose unit	1	138	Seat	1
101	Explosion-safe valve	1	140	Screw M8x10	6
102	Axle	1	141	Rubber washer	6
103	Circlip 20	2	142	Protecting screen	1
104	Packing cup	1	143	Circlip 25	8
105	Packing ring	1	144	Nylon pulley	2
106	Wearing strap 1	1	145	Spacer	10
107	Piston	1	146	Bearing 6005Z	8
108	Spacer sleeve	1	147	Axle 1	2
109	Wire circlip 25	1	148	Chain wheel	4
110	Piston rod	1	149	Axle 2	2
111	O-ring (50)	1	150	Third stage	1
112	Wearing strap 2	1	151	Chock	1
113	O-ring (30)	1	152	Screw M5x10	2
114	Cylinder cap	1	153	Washer 14	4
115	Dust seal	1	154	Increaser	1
116	Roller	12	155	Screw nut	1